

P8F SLIDER, RECESS OR CORNER



I200, I300, I400, I500

Installation Instructions

Please read these instructions throughout before installing as incorrect fitting will invalidate the guarantee.
If you are unsure about these instructions please Kudos Shower Products 01539 564040.

HEALTH & SAFETY WARNING

DUE TO THE WEIGHT & SIZE OF THE GLASS PANEL(S) A MINIMUM OF TWO PERSONS ARE REQUIRED TO MOVE AND INSTALL THIS ENCLOSURE



Tools Required



Pozi-head Screwdriver




Clear Silicone Sealant



Appropriate 7mm Drill Bit



Drill (Battery or Mains)



Spirit Level



Tape Measure



Scissors



Pencil

Cleaning - General

For the wall post and fixings use only warm soapy water and damp cloth/ sponge on a regular basis. After cleaning please rinse with clean water to remove any residue.

Do not use abrasive scouring powders, chemicals or aerosol cleaners - these may result in damage to the surfaces, in particular, the plated component parts.

Glass Treatment

The glass panels are pre-treated with a protective coating on the inside surfaces only. Whilst this makes cleaning the glass easier and helps prevent the build up of harmful lime-scale and soap deposits, the glass still needs to be maintained on a regular basis. We recommend the use of a detergent and aroma free glass cleaner (A 50/50 mix of white vinegar and water works well)

DO NOT use strong detergents, abrasive cleaners or abrasive scrubbing equipment for cleaning, these can damage the coating.

DO use a squeegee to remove remaining droplets of water from glass after showering, any build up of residue can be removed easily using an appropriate cleaner and agitation from soft cleaning equipment

Important

Check appearance of all product - any defects must be reported to your retailer before assembly/installation. Claims for imperfections will only be accepted prior to assembly/installation.

Any claims made under the terms of the Lifetime Guarantee must be reported to your retailer within 21 days of the fault occurring


Check the enclosure adjustment sizes are suitable for your installation.

Use care when drilling into the walls to avoid hidden pipes or electric cables.

Shower Tray

Ensure the top of shower tray is LEVEL in ALL directions.


Once the tray is installed but before the wall tiles are fitted, any gap between the tray and the walls must be filled with silicone sealant flush with the top of the tray.



Stage 1

Once the walls have been tiled but before the enclosure is installed, the tiles must be silicone sealed to the tray all of the way around in one continuous bead.

Failure to follow these instructions will result in leakage problems.



Stage 2

THESE INSTRUCTIONS ARE TO BE LEFT WITH THE CONSUMER

Product Sizes and Adjustments

PRODUCT	PACK CODES		DIMENSIONS (mm)
SLIDER RECESS	RECESS IN-LINE PANEL PACK	DOOR PACK (X = L or R)	A
1200	FSIP-A	FSDR-X/H-A	1165 to 1205
1300	FSIP-B	FSDR-X/H-A	1265 to 1305
1400	FSIP-B	FSDR-X/H-B	1365 to 1405
1500	FSIP-C	FSDR-X/H-B	1465 to 1505

ENCLOSURE HEIGHT = 2000mm




Left Hand Configuration Shown

Product Sizes and Adjustments

PRODUCT	PACK CODES		DIMENSIONS (mm)
SLIDER CORNER	CORNER IN-LINE PANEL PACK	DOOR PACK (X = L or R)	A
1200	FSIP-A	FSDR-X/H-A	1170 to 1190
1300	FSIP-B	FSDR-X/H-A	1270 to 1390
1400	FSIP-B	FSDR-X/H-B	1370 to 1390
1500	FSIP-C	FSDR-X/H-B	1470 to 1490

PRODUCT	PACK CODES	DIMENSIONS (mm)
SIDE PANEL	SIDE PANEL PACK	B
700	P8FPSP70	670 to 690
760	P8FPSP76	730 to 750
800	P8FPSP80	770 to 790
900	P8FPSP90	870 to 890
1000	P8FPSP100	970 to 990
1200	P8FPSP120	1170 to 1190

ENCLOSURE HEIGHT = 2000mm




Left Hand Configuration Shown

Important


FOR CORNER INSTALLATION GO TO PAGE 10

Parts List

Door Pack for Recess & Corner




Inline Panel for Corner & Recess



Installation Steps



Step 1 - Mark out wall posts

1. Position wallpost for fixed panel (with fitted seal to outside) 15mm in from front edge of tray, as shown below. Using spirit level to ensure wallpost is vertical, mark through the 3 slots onto the wall surface as shown and remove wallpost.
2. Position In Line panel wallpost (with fitted seal to outside) 15mm in from front edge of tray, as shown below. Using spirit level to ensure wallpost is vertical, mark through the 3 slotted holes onto the wall surface and remove wallpost.



Step 2 - Drill Mounting Holes


1. Remove the wallposts. Placing safely off to one-side.
2. Using a 7mm masonry drill bit and drill (or appropriate drill bit if drilling tiles), drill three holes for the door wallpost and three holes for the inline panel wallpost using the 'spot' marks from step 2, each hole should be 30mm in depth.
3. Insert the six '8mm Wall Plugs' into the eight holes.



30mm deep


Step 3 - Fix Wallposts

1. Fix wallposts using 6 x No.8x30 PH S/S Screws provided. Tighten all screws using pozi-head screwdriver, ensuring the wallpost is vertical.



Step 4 - Fit Bottom Trim To Fixed Panel


1. Take note of label '**This surface to outside**' this will determine which is the bottom edge of your installation.
 2. Acquire the WTR-0001 Trim from the Side Panel Pack. Peel off a small length of the bottom trim adhesive tape and apply to bottom of glass panel 15mm from the end that will be going into the wallpost, as shown. Continue along length of trim, peeling away the tape as you go, until the full trim length is adhered to the panel.
- Use small upturned edges on bottom trim against chamfered glass edges to ensure trim is fitted centrally.



15mm

Step 5 - Fit Fixed Panel


1. Carefully fit glass side panel into slot in wallpost, ensuring panel is parallel to tray edge.
2. Ensure outer edge of side panel is vertical, as shown, using spirit level.



Step 6 - Insert Push-In Seal

1. Take 'Push-In Seal', Insert the seal to the inside of the enclosure, between the side glass panel and lip of the metal on post, ensuring the curved surface is contacting the glass. Start at the top and work downward, until the seal is fully inserted all the way down the panel, if tight, lubricate the seal with water.

Push In seal can be removed, by inserting tool supplied or allen key to pull the channel out at the top.




Inside view

Step 7 - Fit Bottom Trim To In-Line Panel


1. Take note of label 'This surface to outside' this will determine which is the bottom edge of your installation.
2. Clean glass edge, then make sure it's completely dry.
3. Acquire the WTR-0001 Trim. Peel off a small length of the bottom trim adhesive tape and apply to bottom of glass panel 15mm from the end that will be going into the wallpost, as shown. Make sure no 'dirt' gets on the adhesive strip. Continue along length of trim, peeling away the tape as you go, until the full trim length is adhered to the panel.

Use small upturned edges on bottom trim against chamfered glass edges to ensure trim is fitted centrally.




Step 8 - Fit Inline Panel

1. Carefully fit glass side panel into slot in wallpost, ensuring panel is parallel to tray edge.
2. Ensure outer edge of side panel is vertical, as shown, using spirit level. Often shower trays have different angled top faces, in order to help keep the glass supported use the 'Shim (M193-01)' supplied. **On the inside** of the enclosure measure the gap between the bottom of the glass and top of the tray, select the height required from the shim strip supplied, break off and insert under rail. The shim will be concealed by silicone sealant later.




120-130 door X = 525mm
140-150 door X = 625mm



Step 9 - Insert Push-In Seal


1. Take 'Push-In Seal, Insert the seal to the inside of the enclosure, between the side glass panel and lip of the metal on post, ensuring the curved surface is contacting the glass. Start at the top and work downward, until the seal is fully inserted all the way down the panel, if tight, lubricate the seal with water.

Push In seal can be removed, by inserting tool supplied or allen key to pull the channel out at the top.




Step 10 - Fit Top Rail

1. Loosen the factory fitted screws shown, you may need to remove the screws completely. Lower the rail onto the glass. If the rail doesn't line up, the panels may need adjusting, see step 8 for the dimension between the inline panel and fixed panel.




Step 11 - Fit Top Rail

1. Once the rail is fitted onto the glass panels, tighten the screws shown to secure the rail to the glass.




Step 12 - Check and loosen Bottom Guide

1. Take DCM203-ASM, check that both inner gaskets are present as shown below (highlighted in red). Unscrew the grub screw to loosen the clamp, take care not to unscrew the grub screw fully.



Step 13 - Fit Slider Guide to Glass and Tray


1. To help secure bottom door guide to the glass and the tray we recommend applying a pea sized amount of silicone to the tray where the bottom door guide will be situated. (Silicone shown in green)
 2. Push the bottom door guide onto the in-line panel and push it down on to the pea sized amount of silicone.
 3. Once you are happy with the positioning of the bottom door guide tighten the grub screw to secure the bottom door guide to the in-line panel.
 4. Push in the pad M204-01.
- For this step we recommend using fast curing silicone (1 hour curing silicone) as the slider guide should be fitted and left to cure before proceeding.



Step 14 - Fit Door

1. Ensuring handle hole in sliding door is on the correct side, carefully lift the door through the opening.
2. Lift the door glass and insert both sets of wheels into the running channel of the top rail.

TIP – Using a slightly damp cloth, thoroughly clean the top rail running channel before fitting the sliding door.




Step 15 - Adjusting Door Glass

From the outside check the vertical alignment of door glass against the vertical corner seal on side panel.

If necessary, the door can be adjusted from the inside, by loosening the M5 screw/s (do not remove) and moving wheel/s up or down as shown, to achieve correct alignment.


M5 screws must be fully tightened on completion.

TIP – use your foot to support weight of door whilst adjusting. Adjust and then tighten one wheel set at a time.




Step 16 - Add Door Seal PLEXRF-057

Add the prepared Door Seal PLEXRF-057 to the bottom edge of the Door. Orientation as shown, with the water ramp on the inside of the enclosure. Take care applying the seal due to the limited space available. If you are having difficulty fitting the seal, you can lubricate the seal with a damp clean cloth. The water will evaporate over time – do not use silicone spray or any other substance other than water, these will not fully dry out and will compromise the grip of the seal.




Step 18 - Add Door and inline panel seal

Take both PLEXRF-024 seals, the longer of the two seals is fitted on to the door. Line the seal up with the top of the door and work your way down the seal pushing it on to the door. The shorter PLEXRF-024 seal is to be fitted on to the in-line panel. Ensure the seal is fitted behind the clear fin protruding from the rail. The seals should meet as shown below when the door is closed, this ensures the enclosure is watertight.




The PLEXRF-027 seal fitted to the door will need notched top and bottom in order to clear the top rail and the bottom slider guide. The top notch does not need to be cut all the way to the hard plastic, only enough to clear the rail. Dimensions shown on images. we recommend using scissors to cut seals.




Step 17 - Tighten slider guide

1. Carefully move the door to the open position. Take the remaining part of the slider guide from the installation pack and push it against the door seal as show below.




Once you have the slider guide in position take the washer and screw provided and secure both parts of the slider guide together. Then press the cap in as shown.




Step 19 - Fit Fixed Panel Seal

Take PLEXRF-026 and fit onto the fixed Panel, starting at the top and working your way down the seal. Ensure the seal is fitted behind the clear fin protruding from the rail.




Step 20 - Insert Wallpost End Caps

1. Add the End Caps (M503-01 & M502-01) to the Wallposts as shown below. The wall post cover caps are a safety feature and if they are not fitted the warranty will be void.




Step 21 - Silicone and Apply Water Threshold Strip


1. Check you have received the correct end caps for the PD199 threshold strip. M266 is used for the side butting up to the bottom slider guide, M501 is used for side butting up to the fixed Panel.



2. Silicone the end caps. Silicone a 'pea' sized amount, as shown.
3. Insert the end caps to the Threshold Extrusion ends and silicone the underside of the threshold strip, as shown. Use a thin small amount of silicone.



5. Carefully add the siliconed strip into position, as shown. Make sure the end caps touch up to the inline panel and the the fixed panel.




Step 22 - Silicone

1. On the outside, silicone around all three junctions with the wall and tray, and also on the wallposts where the sill meets the uprights. On the inside, only silicone along the two vertical junctions with the wall. **Do not silicone seal on the inside of unit (except where shown)**. Sealing the wall posts to the tray on the inside can result in leakage problems - please note that, in use, water can penetrate into the extrusions - this has no detrimental effect to the product- however, this water must be allowed to drain out of the extrusions to the inside.

2. Apply a small bead of sealant to top of corner seal to prevent ingress of dirt between seal and glass panels, as shown.


When installed correctly, Kudos guarentee the enclosure will not leak under normal showering use, ie. when the shower head is in it's normal showering position. N.B. - Using the shower head to clean/rinse down the enclosure does not constitute normal showering use.



3. Allow 24 hours before using the shower.




SILICONE ALONG SHIM ONLY




Parts List


Door Pack for Recess & Corner



Inline Panel for Corner & Recess




Side Panel for Corner



Installation Steps



Step 1 - Position and Mark Wallposts

1. Position wallpost for fixed panel (with fitted seal to outside) 15mm in from front edge of tray, as shown below. Using spirit level to ensure wallpost is vertical, mark through the 3 slots onto the wall surface as shown and remove wallpost.
2. Position side panel wallpost (with fitted seal to outside) Xmm in from front edge of tray, as shown below. Using spirit level to ensure wallpost is vertical, mark through the 3 slotted holes onto the wall surface and remove wallpost.




Step 2 - Drill Mounting Holes

1. Remove the wallposts. Placing safely off to one-side.
2. Using a 7mm masonry drill bit and drill (or appropriate drill bit if drilling tiles), drill three holes for the door wallpost and three holes for the inline panel wallpost using the 'spot' marks from step 2, each hole should be 30mm in depth.
3. Insert the six '8mm Wall Plugs' into the eight holes.




Step 3 - Fix Wallposts

1. Fix wallposts using 6 x No.8x30 PH S/S Screws provided. Tighten all screws using pozi-head screwdriver, ensuring the wallpost is vertical.




Step 4 - Fit Bottom Trim To Side Panel

1. Take note of label 'This surface to outside' this will determine which is the bottom edge of your installation.
 2. Acquire the WTR-0001 Trim from the Side Panel Pack. Peel off a small length of the bottom trim adhesive tape and apply to bottom of glass panel 15mm from the end that will be going into the wallpost, as shown. Continue along length of trim, peeling away the tape as you go, until the full trim length is adhered to the panel.
- Use small upturned edges on bottom trim against chamfered glass edges to ensure trim is fitted centrally.



Step 5 - Fit Side Panel


1. Carefully fit glass side panel into slot in wallpost, ensuring panel is parallel to tray edge.
2. Position outer edge of side panel **23mm** back from the front edge of tray, as shown.
3. Ensure outer edge of side panel is vertical, as shown, using spirit level.



Step 6 - Insert Push-In Seal

1. Take 'Push-In Seal', Insert the seal to the inside of the enclosure, between the side glass panel and lip of the metal on post, ensuring the curved surface is contacting the glass. Start at the top and work downward, until the seal is fully inserted all the way down the panel, if tight, lubricate the seal with water.


Push In seal can be removed, by inserting tool supplied or allen key to pull the channel out at the top.



Step 7 - Fit Bottom Trim To In-Line Panel


1. Take note of label 'This surface to outside' this will determine which is the bottom edge of your installation.
2. Clean glass edge, then make sure it's completely dry.
3. Acquire the WTR-0001 Trim from the In-line Panel Pack. Peel off a small length of the bottom trim adhesive tape and apply to bottom up to the vertical edge. Continue along length of trim, peeling away the tape as you go, until the full trim length is adhered to the panel.

Use small upturned edges on bottom trim against chamfered glass edges to ensure trim is fitted centrally.



Step 8 - Fit Glass to Glass Corner Seal


1. Fit glass to glass corner seal to edge of side glass panel. Note orientation of seal. Make sure the seal is fully inserted from bottom to top, use your thumb to apply pressure, as shown. Note there should be a gap at the top for the casting component



If tight, lubricate corner seal and glass edges with a damp **CLEAN** cloth to ease fitment - the water will evaporate over a short period. **DO NOT USE** silicone spray or any other substance other than water, these will not fully dry out and will compromise the grip and rigidity of the joint.

Step 9 - Fit in Line panel Panel


1. Carefully insert the In-line Panel into corner seal, ensuring panel is parallel to tray edge.
2. Ensure In-line Panel is square to first panel. Corner seal must be fully inserted onto both panels.
3. Ensure outer edge of side panel is vertical, as shown, using spirit level. Often shower trays have different angled top faces, in order to help keep the glass supported use the 'Shim (M193-01)' supplied. **On the inside** of the enclosure measure the gap between the bottom of the glass and top of the tray, select the height required from the shim strip supplied, break off and insert under rail. The shim will be concealed by silicone sealant later.



Step 10 - Fit Fixed Panel

1. Carefully fit glass In-line panel into slot in wallpost, ensuring panel is parallel to tray edge.
2. Position the in-line panel, so that there is the required distance between the in-line panel and the fixed panel, see diagram below for measurement.
3. Ensure outer edge of In-line panel panel is vertical, as shown, using spirit level.


120-130 door X = 525mm
140-150 door X = 625mm



Step 11 - Insert Push-In Seal


1. Take 'Push-In Seal, Insert the seal to the inside of the enclosure, between the In-line glass panel and lip of the metal on post, ensuring the curved surface is contacting the glass. Start at the top and work downward, until the seal is fully inserted all the way down the panel, if tight, lubricate the seal with water.

Push In seal can be removed, by inserting tool supplied or allen key to pull the channel out at the top.




Step 12 - Fit Top Rail

1. Loosen the factory fitted screws shown, you may need to remove the screws completely. Lower the rail onto the glass. If the rail doesn't line up, the panels may need adjusting, see step 8 for the dimension between the inline panel and fixed panel.





Step 13 - Fit Top Rail

1. Once the rail is fitted onto the glass panels, tighten the screws shown to secure the rail to the glass.




Step 14 - Check and loosen Bottom Guide

1. Take DCM203-ASM, check that both inner gaskets are present as shown below (highlighted in red). Unscrew the grub screw to loosen the clamp, take care not to unscrew the grub screw fully.




Step 15 - Fit Slider Guide to Glass and Tray

1. To help secure bottom door guide to the glass and the tray we recommend applying a pea sized amount of silicone to the tray where the bottom door guide will be situated. (Silicone shown in yellow)
 2. Push the bottom door guide onto the in-line panel and push it down on to the pea sized amount of silicone.
 3. Once you are happy with the positioning of the bottom door guide tighten the grub screw to secure the bottom door guide to the in-line panel.
 4. Push in the pad M204-01.
- For this step we recommend using fast curing silicone (1 hour curing silicone) as the slider guide should be fitted and left to cure before proceeding.




Step 16 - Fit Door

1. Ensuring handle hole in sliding door is on the correct side, carefully lift the door through the opening.
 2. Lift the door glass and insert both sets of wheels into the running channel of the top rail.
- TIP – Using a slightly damp cloth, thoroughly clean the top rail running channel before fitting the sliding door.




Step 18 - Add Door Seal PLEXRF-057

Add the prepared Door Seal PLEXRF-057 to the bottom edge of the Door. Orientation as shown, with the water ramp on the inside of the enclosure. Take care applying the seal due to the limited space available. If you are having difficulty fitting the seal, you can lubricate the seal with a damp clean cloth. The water will evaporate over time – do not use silicone spray or any other substance other than water, these will not fully dry out and will compromise the grip of the seal.




Step 20 - Add Door Seal and inline panel seals

Take both PLEXRF-024 seals, the longer of the two seals is fitted on to the door. Line the seal up with the top of the door and work your way down the seal pushing it on to the door. The shorter PLEXRF-024 seal is to be fitted on to the in-line panel. Ensure the seal is fitted behind the clear fin protruding from the rail. The seals should meet as shown below when the door is closed, this ensures the enclosure is watertight.



The PLEXRF-027 seal fitted to the door will need notched top and bottom in order to clear the top rail and the bottom slider guide. The top notch does not need to be cut all the way to the hard plastic, only enough to clear the rail. Dimensions shown on images. we recommend using scissors to cut seals.




Step 17 - Adjusting Door Glass

From the outside check the vertical alignment of door glass against the vertical corner seal on side panel.

If necessary, the door can be adjusted from the inside, by loosening the M5 screw/s (do not remove) and moving wheel/s up or down as shown, to achieve correct alignment.


M5 screws must be fully tightened on completion.

TIP – use your foot to support weight of door whilst adjusting. Adjust and then tighten one wheel set at a time.




Step 19 - Tighten slider guide

1. Carefully move the door to the open position. Take the remaining part of the slider guide from the installation pack and push it against the door seal as show below.




Once you have the slider guide in position take the washer and screw provided and secure both parts of the slider guide together. Then press the cap in as shown.




Step 21 - Add fixed panel seal

Take PLEXRF-026 and fit onto the fixed Panel, starting at the top and working your way down the seal. Ensure the seal is fitted behind the clear fin protruding from the rail.




Step 22- fit Corner Casting

Take the corner casting component and lower it onto the corner where the side panel meets the in-line panel. Once you are happy it is in position, tighten the two grub screws.




Step 21 - Silicone and Apply Water Threshold Strip


1. Check you have received the correct end caps for the PD199 threshold strip. M266 is used for the side butting up to the bottom slider guide, M501 is used for side butting up to the fixed Panel.



2. Silicone the end caps. Silicone a 'pea' sized amount, as shown.
3. Insert the end caps to the Threshold Extrusion ends and silicone the underside of the threshold strip, as shown. Use a thin small amount of silicone.




5. Carefully add the siliconed strip into position, as shown. Make sure the end caps touch up to the inline panel and the the fixed panel.



Step 23 - Insert Wallpost End Caps

1. Add the End Caps (M503-01 & M502-01) to the Wallposts as shown below. The wall post cover caps are a safety feature and if they are not fitted the warranty will be void.




Step 22 - Silicone

1. On the outside, silicone around all three junctions with the wall and tray, and also on the wallposts where the sill meets the uprights. On the inside, only silicone along the two vertical junctions with the wall. **Do not silicone seal on the inside of unit (except where shown)**. Sealing the wall posts to the tray on the inside can result in leakage problems - please note that, in use, water can penetrate into the extrusions - this has no detrimental effect to the product- however, this water must be allowed to drain out of the extrusions to the inside.

2. Apply a small bead of sealant to top of corner seal to prevent ingress of dirt between seal and glass panels, as shown.

When installed correctly, Kudos guarentee the enclosure will not leak under normal showering use, ie. when the shower head is in it's normal showering position. N.B. - Using the shower head to clean/rinse down the enclosure does not constitute normal showering use.



3. Allow 24 hours before using the shower.



SILICONE ALONG SHIM ONLY

